



## DROP TEST MANIKIN

### FOR PROFESSIONALS WHO SAVE LIVES

Ruth Lee is a family business whose core values revolve around the care of our employees, service to our customers and uncompromising product quality. We are proud to serve YOU, the dedicated professionals who make such a valuable contribution to society.

We employ highly skilled people and source the most durable materials to ensure our products meet the highest international standards.

Our manikins are designed to represent the correct anatomic weight distribution of a real person, and we offer a range of different models to suit every conceivable scenario. This ensures that your training is as realistic and as effective as possible; preparing you for all eventualities.

LEARN MORE ABOUT OUR  
EXTENSIVE RANGE OF  
TRAINING MANIKINS,  
BESPOKE BAGS,  
OPERATIONAL  
PRODUCTS AND FIRE  
SIMULATION EQUIPMENT

SPEAK TO THE EXPERTS:

+44 (0) 1490 413 282 SALES@RUTHLEE.CO.UK WWW.RUTHLEE.CO.UK



# DROP TEST MANIKIN

## IDEAL FOR THE FOLLOWING TRAINING SCENARIOS:

As the name suggests, this manikin is the perfect choice for testing fall arrest equipment and harnesses. It has a more rigid trunk to reduce slumping when suspended in harness and will allow you to properly assess the safety of your fall arrest equipment.

## SPECIAL MATERIALS:

Constructed from the same flame retardant material used in Police ballistic/stab vests, offering 4x the strength and abrasion resistance of 16oz canvas or P.V.C. (Conforms to OEKO-TEX® Standard 100, BS EN ISO 12947-2 & 14116: 2008). High density polypropylene webbing (25mm rated to 207 Kg, 50mm rated to 440Kg).

## FEATURES & BENEFITS:

- Similar in construction to the Duty Range manikins but utilises closed cell foam to the trunk to provide greater rigidity and reduce 'slumping' when using a rescue harness.
- Anatomically correct weight distribution gives the 'feel' of an unconscious person - perfect for pole top or tower rescues.
- Realistic sizes and weight - will demonstrate the difficulties of dealing with an adult unconscious casualty

- Strong Polypropylene webbing loop to the back allows the manikin to be easily hauled into position prior to training.
- Strong enough to be dropped from 2 or 3 storeys with no damage - these manikins are tough!
- The Polyester is waterproof, making it suitable for training in wet or dry conditions as it can be easily cleaned and dried.
- Soft body joints eliminate the risk of pinch welts and bruising, a common injury when using plastic bodied manikins.
- Protective consumables including, coveralls and boots, greatly extended the life of the manikin and help save you costs.

## NOT SUITED FOR:

- Use in temperatures above 100°C or flash-over scenarios – See our Fire House manikin.
- Use in water – See our Water Rescue range.

## OPTIONAL EXTRAS:

- Face mask and wig for a more human-like appearance.

## EXTENSIVELY USED BY:

- Manufacturers of Fall Arrest Equipment.

## AVAILABLE WEIGHTS & SIZES:

DESCRIPTION	MODEL CODE	HEIGHT (M)	WEIGHT (KG)	NATO STOCK #
Drop Test Manikin	RLN100	1.8	100	N/A

\*Manikins weighing over 50kg may have metal ballast as part of their construction. Please contact us for more information.



FOR PROFESSIONALS WHO SAVE LIVES



UPDATED:03.09.20